


KITCHEN SCALE INSTRUCTION MANUAL



Getting started:

1. Place 3 AAA batteries in scale. (not included)
2. Place scale on a firm, level surface.
3. Gently press the scale by hand to turn on. (note: the scale automatically turns off after 2 minutes)

LED display



—	Negative value	○	Zero weight
fl'oz	Weight unit (fl'oz)	⚖	Weight mode
lb:oz	Weight unit (lb:oz)	💧	Water mode
ml	Weight unit (ml)	M	Milk mode
g	Weight unit (g)	⚡	Power

ERR: Indicates scale load has been exceeded.
(max 5 kg. or 11 lb.)

LO: Indicates batteries must be replaced.

Button Functions:

ZERO: Press while an object is on the scale, to set its weight to zero.

UNIT: Cycles between the following modes with each press:

Weight (grams) – Water volume (ml) – Milk volume (ml) – Weight (ounces) – Water volume (fluid ounces) – Milk volume (fluid ounces)

Measuring weight:

1. Place object on scale. Weight is displayed in grams. (note: tap **UNIT** button 3 times to display weight in ounces)
 2. If using a container, place the container on the scale and press the **ZERO** button, then add the items to the container.
-

Measuring liquid volume:

1. Put container on scale and press **ZERO**.
2. Press the **UNIT** button until the desired volume measurement icon is displayed (water/milk, ml/ounces).
3. Add liquid to the container.

Sana Scale Features:

Precise weighing to 5 kg (11 lb.)

Water volume measurement

Milk volume measurement

Metric and imperial measurements

Zero function

Touch to turn on

Auto shut off

LED display

2 year warranty

Care and Use

Clean the scale immediately after use with a slightly damp cloth.

Do not spill any acidic liquids like citrus juice or vinegar on the scale.

Always use the scale on a solid, flat surface.



visit us at

www.sanaproducts.com